



NOTES:

1. IF FLUME IS 7' OR WIDER, USE PIPE BOLLARDS 7'X6" DIA., AND FILL WITH CONCRETE. PLACE AT BOTH START AND END OF FLUME, BURY TO 4' DEPTH.
2. SIDE SLOPES TO BE HYDROMULCHED.
3. CROSS FENCING NOT ALLOWED, UNLESS APPROVED BY CITY ENGINEER. ALL APPROVED CROSS FENCING SHALL BE WROUGHT IRON TYPE.



STORM DRAIN CONSTRUCTION DETAILS
CONCRETE FLUME

REVISION DATE:
2/9/2009

SHEET: D-06